

WareWashing

EXCEL DISHES RENEWER

DESCRIPTION

- Renovation powder for dishes by soaking or in the dishwasher.
- Removes Tannin stains thanks to its bleaching agents.
- Prevents scale deposit in the machine and marks on glasses & cutleries.
- Can be used also as a detergent in an automatic washing cycle at 55-60°C.
- Non foaming.
- Complies with the legislation on the cleaning of food contact equipment .

HOW TO USE

- Renovation: (once or twice a month)
 - Put 3 to 5 g of the product in 1 liter of water in addition to the washing detergent.
 - Rinse manually or through the dishwasher.
- Renovation by soaking: (Deeply embedded dishes with organic deposits).
 - Put 10 to 20 g of the product per liter of warm water
 - Leave to act for 2 Hr.
 - Rinse with clear water.
- Dishwashing detergent:
 - Put 1 to 2 g of the product per liter of water depending on the water hardness and the level of soil.

PRECAUTIONS

- For professional use only.
- For more information consult safety data sheet.

PACKING UNIT

- Bucket 10 Kg.

TECHNICAL DATA

Colour	White
Texture	Powder
PH	10.7
Storage	Dry place